


BOSE[®]



BOSE[®] MIE2 MOBILE HEADSET

Owner's Guide | Guía de usuario | Notice d'utilisation

Welcome

Thank you for purchasing the Bose® MIE2 mobile headset. The Bose® MIE2 mobile headset offers a combination of lifelike audio and communications performance and comfortable fit not available from most conventional earbuds.

Register your product

Now is a good time to register your headset. You can do this easily by going to <http://global.Bose.com/register>.




This product conforms to all EU Directive requirements as applicable by law. The complete Declaration of Conformity can be found at www.Bose.com/compliance.

WARNING: DO NOT use mobile phone adapters to connect headset to airplane seat jacks as this could result in personal injury such as burns or property damage due to overheating. Remove and disconnect immediately if you experience warming sensation or loss of audio.

©2010 Bose Corporation. No part of this work may be reproduced, modified, distributed, or otherwise used without prior written permission. All trademarks referenced herein are property of Bose Corporation.

ENGLISH



Connecting to a mobile phone or audio device

You can connect the headset to your mobile phone with either the 3.5 mm stereo plug (compatible with standard headphone jacks) or by using one of the two included 2.5 mm adapter cables if needed.

The correct connection should allow:


- Stereo sound to be heard during music playback and communications
- Your voice to be heard by the person on the other end of a phone call
- The Answer/End button to operate as expected

Compatible with many music-enabled mobile phones. Refer to the enclosed compatibility list or visit www.Bose.com/phones for the latest list of compatible phones.

Without adapter

If your phone has a 3.5 mm headphone/headset jack, you do not need to use the included adapters.

1. Plug the headset into the headphone/headset jack on the phone.
2. Put on the headset.



● Device with 3.5 mm headphone/headset jack


With adapter

The Bose® MIE2 mobile headset includes two unique phone adapters. Each is identified by a small symbol (circle, triangle) on the top of the plug.

If your phone has a 2.5 mm headphone/headset jack, you will need to use one of these adapters.

1. Select the appropriate adapter.
2. Attach the adapter to the headset cable.
3. Plug the headset with the adapter into the headphone/headset jack on the phone.
4. Put on the headset.

Note: If your phone does not respond when you press the Answer/End button, you are getting partial or no sound, or the microphone is not picking-up sound, you may be using the wrong adapter. Try the other adapter and check again. Refer to www.Bose.com/phones to determine which adapter is compatible with your phone.



● Device with 2.5 mm headphone/headset jack

Answering and ending calls

The Bose® MIE2 mobile headset includes an easy to access Answer/End button with integrated microphone. Simply press the Answer/End button to perform an action.

Note: Some phones may require you to press twice or press and hold the Answer/End button for a few seconds to perform functions.

Answering calls

When you receive an incoming call, press and release the Answer/End button to answer.


Ending calls

When you are ready to end your call, press and release the Answer/End button.

Note: Some unique phone and music playback functions, like last number redial, voice commands, and track navigation are device-dependant, and may be accessible using the Answer/End button. Refer to your mobile phone user's manual to find out what features are available.

Using a single earpiece

The Bose® MIE2 mobile headset can be used with only the right (R) earpiece in your ear. This allows you to take calls and still hear surrounding sounds.




Importance of Proper Fit

When you wear the headset properly, it provides the comfort and clarity you expect from Bose®.

Fitting the headphones to your ear



The headphone earpiece has a soft StayHear™ tip attached, allowing it to rest comfortably in the bowl of your ear. The wing part of the tip fits just under your ear ridge.

Note: Each tip is marked with either an L or an R to indicate which earpiece it is for. Be sure to attach the left StayHear™ tip to the left earpiece and the right StayHear™ tip to the right earpiece.



To determine if the tip is the right size:

1. Insert the earpiece into the canal just enough for the headphone to rest lightly against your ear.
 2. Tilt the headphone back and press the tip wing under the ear ridge until it is secure.
- The tips should fit comfortably yet securely in the bowl of the ear.



Changing ear tips

Select the type and size of eartip that provides you with the best comfort and fit.


1. Gently peel the edges of the attached tip away from the earpiece, using care not to tear the tip.

CAUTION: To prevent damage, do not pull on the StayHear™ tip wing.



2. Position the opening of the new tip over the nozzle and the small slot over the nozzle hook.

Note: Each tip is marked with either an L or an R to indicate which earpiece it is for. Be sure to attach the left StayHear™ tip to the left earpiece and the right StayHear™ tip to the right earpiece.

3. Ease the base of the tip down around the base of the earpiece until the tip feels secured.



StayHear™ tips



Original-style tips

Adjusting for comfort and stability

There are several ways you can adjust your headset to provide additional comfort and stability. Using the adjustment slider and clothing clip you can customize how you wear your headset.


Using the adjustment slider

Move the adjustment slider up or down to reduce or increase the amount of loose cord between the left and right earpiece. Finding the right position for the slider can help optimize the placement of the Answer/End button and integrated microphone.



Using the clothing clip

Use the clothing clip to fasten the cable to your clothing, for convenience, stability, and to help manage the cable. This can be helpful during high-movement activities or when using the headset in a single earpiece configuration.



Troubleshooting

If you experience any trouble using your headset, try the following troubleshooting instructions. If you still need help, see the contact information on the inside back cover for assistance in your area.

Problem	What to do
No audio/intermittent	• Make sure that the headset plug is securely connected to the headphone/headset jack (not the line out jack). • Try another audio device.
Sound is coming from only one earpiece	• Make sure you are using the correct mobile phone adapter and that it is securely connected. • Unplug the headset from the audio source, then plug back in making sure they are securely connected. • Try another audio device.
Incoming call ring tone not heard through headset	• Make sure your phone is set to pass the ring tone through to the headset. Check your phone settings and make adjustments as needed. Note: <i>This feature may not be available on all phones.</i>
Excessive bass	• Turn off any audio enhancement features on the audio source.
Low volume/poor audio	• Turn off any “sound checker” or other audio signal altering features on the audio source. • Make sure ear tips and headset nozzles are clear of any debris or wax build-up. • Make sure the volume level of the audio source is turned up.
Microphone is not picking-up sound	• Make sure you are using the correct mobile phone adapter and that it is securely connected. • Make sure the microphone is not being blocked or covered. <i>The microphone is located on the back of the Answer/End button (you may notice the small opening for the microphone).</i>
Phone not responding when Answer/End button is pressed	• Make sure you are using the correct mobile phone adapter and that it is securely connected. Note: <i>Some phones may require you to press and hold the Answer/End button for a few seconds to perform functions.</i>
Phone unexpectedly ends call	• Some phones will end a call if the headset is unplugged during a call. • Make sure that the headset plug is securely connected to the headphone/headset jack. • Check phone signal strength to ensure network coverage.
Ear tips falling off	• Make sure the ear tips are securely attached to the earpiece and nozzle hook.
Lost ear tip	• Visit owners.Bose.com for replacement tips.
Sound is muffled from earpiece	• Make sure ear tips and headset nozzles are clear of any debris or wax build-up. • Unplug the headset from the audio source, then plug back in making sure they are securely connected. • Try another audio device.

Cleaning

Your headset may require periodic cleaning:

- Ear tips: First, remove them from the headset and wash the tips with a mild detergent and water. Make sure you thoroughly rinse and dry them before putting them back on the headset.
- Headset nozzles, Microphone, Answer/End button: Clean only with a dry, soft cotton swab or equivalent. Never insert any cleaning tool into the nozzle or microphone opening.

WARNINGS:

- *Contains small parts which may be a choking hazard. Not suitable for children under age 3.*  0-3
- *This product contains magnetic material.*
- *Long-term exposure to loud music may cause hearing damage. It is best to avoid high volume levels when using headphones, especially for extended periods.*
- *Use caution when using your headset/headphones while operating a vehicle or engaging in any activity that requires your full attention. Check and follow local laws regarding mobile phone and headset/headphones use. Some jurisdictions impose specific limitations, such as single earpiece configuration, on the use of such products while driving.*

CAUTIONS:

- *Sounds that you rely on as reminders or warnings may have an unfamiliar character when using headphones. Be aware of how these sounds may vary in character so you can recognize them as needed.*
- *Do not drop, sit on, or allow the headset to be immersed in water.*

Limited Warranty

Your Bose® MIE2 mobile headset is covered by a limited warranty. Details of the limited warranty are provided on the product registration card that is included in the carton. Please refer to the card for instructions on how to register. Failure to register will not affect your limited warranty rights.

What you must do to obtain Limited Warranty service

Return the product, with proof of purchase from an authorized Bose dealer, using the following procedures:

1. Contact the Bose organization in your country/region (visit Global.Bose.com for contact information in your country/region) for specific return and shipping instructions.
2. Label and ship the product, freight prepaid, to the address provided by the Bose organization in your country.
3. Place any necessary Return Authorization Number prominently on the outside of the carton. Cartons not bearing a Return Authorization Number, where required, will be refused.

BOSE CORPORATION

USA

The Mountain,
Framingham, MA, 01701
888-757-9943
owners.Bose.com

Canada

9133 Leslie Street,
Suite 120, L4B 4N1
800-905-2177
www.Bose.ca

Australia

Unit 3/2 Holker St. Newington
NSW, 2127
1800 023 367
www.Bose.com.au

Belgique/Belgie

B-3700 Tongeren
012-390800
www.Bosebelgium.be

China

2203-2305 22F, West Gate
Tower/1038 West Nanjing
Road-MeiLongzhen Plaza,
Shanghai, 200041
86-22-62713000 ext. 162
www.Bose.cn

Denmark

2605 Brondby
04343-7777
www.Bose.dk

Deutschland

D-61381 Friedrichsdorf
06172-71040
www.Bose.de

France

78100 Saint Germain en Laye
01-30616363
www.Bosefrance.fr

India

Shriram Bhartiya Kala Kendra,
1 Copernicus Marg, New Delhi,
100-001
91-11-2307-3825-3826-3827
www.Boseindia.com

Ireland

Castlebury Road,
Carrickmacross, Co
Monaghan
042-9671500
www.Bose.ie

Italia

Via della Magliana 876
Roma, 00148
06.60.292.555
www.Bose.it

Japan

Karakida Center bldg., 1-53-9
Karakida, Tama-shi, Tokyo,
2060035
81-423-575250
www.Bose.co.jp

Mexico

Paseo de las Palmas # 405,
11000
52-55-52-02-35-45
FAX: 52-55-52-02-41-95
www.Bose.com.mx

Nederland

1135 GE Edam
0299-390111
www.Bose.nl

New Zealand

0800 501 511
www.Bose.co.nz

Norge

N-2213 Kongsvinger
62-82-15-60
www.Bose.no

Österreich

Wienerbergstrasse 7 (10.OG)
01-60404340
www.Bose.at

Schweiz

Hauptstrasse 134
061-9757733
www.Bose.ch

Sverige

S-43153 Mölndal
031-878850
www.Bose.se

United Kingdom

1 Ambley Green,
Gillingham Business Park,
Gillingham, Kent, ME8 ONJ
0780-741-4500
Info_uk@Bose.com

Hong Kong

Suite 1203, Midas Plaza, 1 Tai
Yau Street, San Po Kong,
Kowloon, Hong Kong
(852) 21239000
support_hk@Bose.com

Finland


Korhonenintie 6b Helsinki, 380
+358 10 778 6900
www.Bose.fi

Poland

ul. Woloska 12
Warszawa, 02-675
+48 (0)22-8522928
www.Bose.pl

World Wide Web

www.Bose.com
www.Boseeurope.com



329520-0010

BOSE®
Better sound through research®

©2010 Bose Corporation, The Mountain,
Framingham, MA 01701-9168 USA
AM329520 Rev.00

ก่อนที่จะเริ่มต้น...

ผลิตภัณฑ์ Bose® in-ear ได้รับการออกแบบให้สวมใส่ได้อย่างสบายในช่องหูที่รอบนอกของช่องหู ด้วยเหตุนี้ ความรู้สึกเมื่อใช้ครั้งแรกอาจแตกต่างไปจากที่เคย โปรดอ่านคู่มือผู้ใช้ของคุณเกี่ยวกับข้อมูลการเลือกขนาดจุกสวมหูที่เหมาะสมสำหรับการสวมใส่ของคุณ

使用前的准备工作 ...

Bose® 入耳式产品设计用于舒适地贴放于耳朵里耳道外的位置。正因为如此，最初可能稍微感不适应。请参考您的用户指南，了解有关如何选择适合自己的耳机的信息。

قبل أن تبدأ...

منتجات Bose® in-ear مصممة بحيث تستقر بشكل مريح في تجويف أذنك خارج القناة السمعية. ولذلك قد تبدو مختلفة في البداية. يرجى الرجوع إلى دليل المالك للحصول على معلومات عن اختيار الحجم الصحيح لسدادة الأذن بالنسبة لك.

Before you begin...

Før du begynder...

Bevor Sie beginnen...

Antes de comenzar...

Avant de commencer...

Prima di iniziare...

Voordat u begint...

Innan du börjar...

ก่อนที่จะเริ่มต้น...

시작하기 전에...

使用前的准备工作 ...

使用前的准备工作 ...

قبل أن تبدأ...

시작하기 전에...

使用前的准备工作 ...

Bose® in-ear 제품은 귓속이 아닌 바로 바깥의 오목한 부분에 편안히 자리잡도록 설계되었습니다. 그렇기 때문에 처음 사용하는 경우 느낌이 약간 다를 수 있습니다. 사용자에게 맞는 올바른 이어 팁을 선택하려면 사용자 안내서에서 해당 정보를 참조하십시오.

Bose® 入耳式產品設計用於舒適地貼放於耳朵裏耳道外的位置。正因為如此，最初可能稍微感不適應。請參考您的用戶指南，瞭解有關如何選擇適合自己的耳機的資訊。



331474-0001

BOSE[®]
Better sound through research[®]

Before you begin...

Bose® in-ear products are designed to nestle comfortably in the bowl of your ear just outside the ear canal. Because of this, they may feel different at first. Please refer to your Owner's Guide for information about choosing the ear tip that is right for you.

Bevor Sie beginnen...

Bose® In-Ear-Produkte sollen bequem in der Ohrmuschel außerhalb des Gehörganges sitzen. Dies kann sich am Anfang etwas ungewöhnlich anfühlen. Informationen zur Auswahl der für Sie richtigen Polsterkappe finden Sie in der Bedienungsanleitung.

Avant de commencer...

Les casques audio Bose® intra-auriculaires sont conçus pour reposer en douceur dans le creux de l'oreille, à l'extérieur du conduit auditif. C'est pourquoi la première utilisation peut surprendre. Reportez-vous à la notice d'utilisation pour toutes informations sur le choix du coussinet qui vous convient le mieux.

Voordat u begint...

De in-ear-producten van Bose® zijn bedoeld om in de schelp van uw oor te dragen, net buiten het gehoorkanaal. Daarom kunnen deze in het begin wat vreemd aanvoelen. Zie de gebruikershandleiding voor informatie over de juiste oordopjes.

Før du begynder...

In-ear produkter fra Bose® er designet til at sidde komfortabelt i ørehulen lige uden for øregangen. Derfor kan de til at begynde med føles anderledes. I brugervejledningen kan du finde oplysninger om, hvordan du vælger den øreindsats, der er den rigtige for dig.

Antes de comenzar...

Los auriculares internos Bose® se han diseñado para ajustarse con comodidad al pabellón auditivo, justo fuera del oído. Por ello, es posible que al principio produzcan una sensación distinta de la habitual. Consulte la Guía del usuario para seleccionar las almohadillas del auricular adecuadas para usted.


Prima di iniziare...

I prodotti Bose® in-ear sono realizzati per adattarsi comodamente all'incavo dell'orecchio, appena fuori del canale uditivo. Per questo motivo, inizialmente potrebbero dare una sensazione insolita. Consultare il manuale di istruzioni per imparare a scegliere il puntale giusto per il proprio orecchio.

Innan du börjar...

Bose®-hörlurar som du sätter fast i örat utanför hörselgången är anpassade för ytterörat. På grund av denna design kan de till att börja med kännas obekväma. I bruksanvisningen finns information om hur du byter öronproppar.

Also available



Welcome to a quieter world. Most people who purchase Bose products appreciate the pleasure that listening to music can bring. If you sometimes find that distractions prevent you from enjoying your music as you'd like, you should consider QuietComfort headphones from Bose. **Choose QuietComfort 15 headphones, our best-performing headphones. Or QuietComfort 3 headphones if you prefer a smaller, on-ear alternative.**

With either, you'll enjoy our acclaimed noise reduction technology, along with lifelike Bose sound, a lightweight fit that stays comfortable for hours and the quality you expect from Bose. It's a combination of benefits that remains unmatched in the industry.

Acclaimed noise reduction – and Bose quality sound.


Unwanted noise is everywhere. The engine roar inside an airplane cabin. The bustle of the city. The distractions in the office. QC15 and QC3 headphones help them fade softly into the background – all at the flick of a switch. And because they're so comfortable, you may even forget you're wearing them.

Our QuietComfort headphones were designed primarily for airplane travelers. Owners soon started telling us how much they enjoy using them in other places to listen to music or work on their computers – whether on the go, at home or in the office. QuietComfort headphones incorporate proprietary technology that electronically identifies unwanted noise and fades it into the background, while faithfully preserving the music, movie dialogue or tranquility you desire.

Hear the difference Bose® technology makes.

We began researching noise reduction more than 30 years ago. Now, our decades of research and experience combine with our proprietary technologies in these advanced noise reducing headphones from Bose. Experience them for yourself.

QC®15 headphones.
Our best-performing headphones.



QC®3 headphones.
For a smaller, on-ear fit.



Each folds flat for easy storage in its slim carrying case.

**Learn more about our
Acoustic Noise Cancelling® headphones
and our audio headphones at www.Bose.com.**

**Try Bose QuietComfort® headphones
for a 30-day trial.**

**In the USA, call 1-800-760-2758, ext. Q2028
or visit us online at www.Bose.com/allheadphones.
Outside the USA, visit us online at www.Bose.com.**

BOSE®
Better sound through research®



Warranty information inside
Register your product now

Contiene información sobre la garantía
Registre su producto ahora



Renseignements sur la garantie à l'intérieur
Enregistrez votre produit dès maintenant



Serial number:

Número de serie:

Numéro de série :



Registre su producto.* Conozca toda la gama de servicios que su garantía le ofrece.

Registrarse en línea es fácil y rápido.
Global.Bose.com/register

Enlace directo para registrarse:

www.register.Bose.eu (Europa)

www.Bose.com/register (EE.UU., Puerto Rico
e Islas Virgenes de EE.UU.)

www.Bose.com.au/warranty (Australia)

www.Bose.ca/register (Canadá)

www.Bose.co.nz/warranty (Nueva Zelanda)

Envíe cualquier correspondencia en relación con información de productos o los servicios de la Garantía limitada a la sede corporativa de la empresa en:

Registro del producto
Bose Corporation
The Mountain
PO Box 9168
Framingham, MA 01701-9168 EE.UU.

1-800-736-5076 (EE.UU.)
1-508-766-1000 (INTL) *Es posible que se apliquen cargos por la llamada. Tenga a mano el número de serie cuando realice la llamada.*
Los propietarios que vivan fuera de los Estados Unidos deben revisar la Guía del usuario o ir a Global.Bose.com para encontrar la dirección más cercana.

GARANTÍA LIMITADA

A quién cubre:
Esta garantía se extiende únicamente al comprador final original o a la persona que reciba el producto como regalo y no se extenderá a cualquier otra persona o beneficiario.

Qué se cubre/ Por cuánto tiempo:
A menos que un período de garantía diferente se especifique en la Guía del usuario provista con su producto Bose; por un período de 1 año (2 años en la UE.) [5 años para altavoces no eléctricos incorporados en el producto] a partir de la fecha de la compra minorista por parte del usuario final original, Bose garantiza que este producto, cuando se le entrega en su paquete original y en nueva condición, por parte de un revendedor autorizado por Bose y es utilizado en condiciones normales, no tiene defectos de fabricación, de materiales ni de producción.

Qué es lo que no se cubre:
Esta garantía no cubre defectos ocasionados por prácticas de uso o mantenimiento incorrectas o no razonables, el incumplimiento de las instrucciones de uso; accidentes; humedad excesiva; insectos; rayos; subidas de tensión; conexión a voltaje incorrecto; alteraciones o modificaciones no autorizadas del producto original; daños causados por embalaje o proceso de envío inadecuado; pérdida, daño o alteración de la información guardada; daños ocasionados por el uso con productos que no sean de Bose; productos que requieren de modificación o adaptación para permitir que se utilicen en cualquier país fuera del país para el que fueron diseñados,

fabricados, aprobados y/o autorizados, o reparación de productos dañados por estas modificaciones; y productos adquiridos de vendedores no autorizados.

Qué haremos:
Durante el período de garantía repararemos o sustituiremos, a nuestra discreción, las partes defectuosas en un período razonable de tiempo y sin cargo utilizando repuestos nuevos o rehabilitada.

Qué es lo que no haremos:
Pagar cargos por envío, seguros o transporte del producto de usted a nosotros, tasas de importación o impuestos.

Qué debe hacer para obtener el servicio de la Garantía limitada:
Devuelva el producto con el comprobante de compra emitido por un vendedor autorizado de Bose, realizando los siguientes pasos:

1. Contáctese con la compañía Bose en su país/ región (visite Global.Bose.com para obtener información de contacto en su país/región) a fin de obtener instrucciones específicas sobre devolución y envío;
2. Rotule y envíe el producto, con flete pago, a la dirección de la compañía Bose en su país; y
3. Coloque cualquier número de autorización para la devolución que sea necesario en forma visible y en la parte exterior del paquete. Los paquetes que no tengan un número de autorización de devolución, cuando sea necesario, serán rechazados.

Otras condiciones:
LAS DISPOSICIONES DE ESTA GARANTÍA LIMITADA REEMPLAZAN CUALQUIER OTRA GARANTÍA, YA SEA EXPRESA O IMPLÍCITA, ESCRITA U ORAL, INCLUYENDO CUALQUIER GARANTÍA DE COMERCIABILIDAD O ADECUACIÓN A UN FIN PARTICULAR. LA RESPONSABILIDAD MÁXIMA DE BOSE CORPORATION NO PUEDE EXCEDER EL PRECIO DE COMPRA REAL QUE USTED PAGÓ POR EL PRODUCTO. BAJO NINGUNA CIRCUNSTANCIA SERÁ BOSE RESPONSABLE POR LA PÉRDIDA, DAÑO O ALTERACIÓN DE INFORMACIÓN GUARDADA O POR DAÑOS ESPECIALES, INCIDENTALES, EN CONSECUENCIA O INDIRECTOS CUALQUIERA SEA LA CAUSA DE LOS MISMOS, INCLUYENDO SIN LIMITACIÓN, EL REEMPLAZO DE EQUIPOS Y PROPIEDADES Y CUALQUIER COSTO DE RECUPERACIÓN, PROGRAMACIÓN O REPRODUCCIÓN DE CUALQUIER PROGRAMA O INFORMACIÓN GUARDADA O UTILIZADA CON SU PRODUCTO BOSE. Esta garantía se anula en caso de que la etiqueta con el número de serie haya sido quitada o dañada.

Otros derechos legales:
Esta garantía limitada le otorga derechos legales específicos y es posible que también se le otorguen otros derechos que varían según los estados o países. Algunos lugares no permiten limitaciones en garantías implícitas o la exclusión o limitación por daños secundarios o resultantes, por lo que es posible que las limitaciones o exclusiones anteriores no se apliquen a usted.

Enregistrez votre produit.* Renseignez-vous sur la gamme complète de services offerts dans le cadre de notre garantie.

L'enregistrement en ligne est simple et rapide.
Global.Bose.com/register

Liens directs vers les sites d'enregistrement :

www.register.Bose.eu (Europe)

www.Bose.com/register (États-Unis, Puerto Rico
et Îles Vierges des États-Unis)

www.Bose.com.au/warranty (Australie)

www.Bose.ca/register (Canada)

www.Bose.co.nz/warranty (Nouvelle-Zélande)

Pour toute correspondance relevant d'une demande de renseignements au sujet de nos produits ou de nos services de garantie limitée, veuillez nous écrire à notre siège social, à l'adresse suivante :

Enregistrement de produits
Bose Corporation
The Mountain
PO Box 9168
Framingham, MA 01701-9168 États-Unis

1-800-736-5076 (États-Unis)
1-508-766-1000 (international) *Des frais peuvent s'appliquer. Veuillez avoir en main votre numéro de série lors de l'appel.*

Si vous résidez hors des États-Unis, consultez le guide de l'utilisateur ou le Global.Bose.com pour obtenir l'adresse postale la plus proche.

GARANTIE LIMITÉE

Bénéficiaire :
La présente garantie est uniquement valable pour le premier acheteur ou la personne ayant reçu le produit en cadeau et ne peut en aucun cas être étendue ou transférée à une autre personne.

Objet et durée de la garantie :
À moins qu'une durée différente ne soit indiquée dans le guide de l'utilisateur fourni avec le produit, Bose garantit pendant une période d'un an (deux ans dans l'UE) [cinq ans pour tout haut-parleur non amplifié intégré au produit], à partir de la date d'achat au détail par le premier acheteur, que le produit est libre de tout vice de matériaux et de fabrication lorsqu'il est livré à l'état neuf, dans son emballage d'origine et par un détaillant autorisé Bose, et qu'il est utilisé dans des conditions normales.

Exclusions :
La présente garantie ne couvre pas : les défauts ou dommages résultant d'une utilisation ou d'un entretien inapproprié ou incorrect, du non-respect des directives d'utilisation, d'un accident, d'une humidité excessive, de la présence d'insectes, de la foudre, d'une pointe de courant électrique, d'un raccordement à un courant électrique d'une tension incorrecte, d'une altération ou d'une modification du produit, de procédures d'emballage ou d'expédition inappropriées; la perte, l'altération ou la détérioration de données informatiques; les dommages causés par l'utilisation avec un produit d'une marque autre que Bose; les modifications ou adaptations effectuées au produit pour qu'il soit utilisable dans un pays autre que celui pour lequel il a été conçu, fabriqué,

approuvé et/ou autorisé, de même que la réparation d'un produit endommagé par ces modifications; les produits achetés auprès d'un détaillant non agréé.

Notre engagement :
Au cours de la période de garantie, à notre seule discrétion, nous réparerons ou remplacerons toute pièce défectueuse dans un délai raisonnable, sans frais utilisant nouvel ou rénové les parties de remplacement.

Frais exclus :
La garantie ne couvre pas le paiement des frais d'expédition, d'assurance et de transport du produit vers notre adresse, ainsi que de toutes taxes et de tous droits d'importation ou autres.

Conditions de l'obtention des services de garantie limitée réparation :
Expédiez-nous le produit, accompagné de la preuve d'achat d'origine d'un détaillant Bose autorisé, en suivant les directives ci-dessous :

1. Communiquez avec l'entité Bose de votre pays ou région (consultez le site Global.Bose.com pour connaître les coordonnées de Bose dans votre pays ou région) pour obtenir les instructions de retour et d'expédition particulières;
2. Étiquetez et expédiez le produit, en port payé, à l'adresse fournie par l'entité Bose de votre pays ou région; et
3. Inscrivez de façon très visible sur l'extérieur de l'emballage tout numéro d'autorisation de retour nécessaire. Un envoi qui ne comporte pas de numéro d'autorisation de retour lorsque celui-ci est requis sera refusé.

Autres conditions :
LES CONDITIONS DE LA PRÉSENTE GARANTIE LIMITÉE REMPLACENT TOUTE AUTRE GARANTIE, EXPRESSE OU IMPLÍCITE, EXPRIMÉE PAR ÉCRIT OU ORALEMENT, Y COMPRIS TOUTE GARANTIE DE QUALITÉ MARCHANDE OU D'ADAPTATION À UN USAGE PARTICULIER. LA RESPONSABILITÉ MAXIMALE DE BOSE CORPORATION ÉQUIVAUT AU PRIX PAYÉ PAR LE CONSOMMATEUR À L'ACHAT DU PRODUIT. BOSE NE PEUT EN AUCUN CAS ÊTRE TENUE RESPONSABLE DE LA PERTE, DE L'ALTÉRATION OU DE LA DÉTÉRIORATION DE DONNÉES INFORMATIQUES, NI DE DOMMAGES PARTICULIERS, ACCESSOIRES OU INDIRECTS, QUELLE QU'EN SOIT LA CAUSE, Y COMPRIS, SANS RESTRICTION, LE REMPLACEMENT D'EQUIPEMENT ET DE BIENS ET TOUTS FRAIS DE RECUPÉRATION, DE PROGRAMMATION OU DE REPRODUCTION DE TOUT PROGRAMME OU DE TOUTES DONNÉES ENREGISTRÉES DANS LE PRODUIT BOSE OU UTILISÉES AVEC CELUI-CI. La présente garantie est annulée si l'étiquette portant le numéro de série est retirée ou altérée.

Autres droits :
La présente garantie limitée vous confère des droits particuliers selon la loi; vous pouvez aussi bénéficier d'autres droits qui varient selon votre pays ou région de résidence. Certains territoires ne permettant pas la limitation des garanties implicites ou l'exclusion ou la limitation des dommages indirects ou accessoires, il est donc possible que les limites ou exclusions ci-dessus ne s'appliquent pas à vous.

*En caso de que no registre su producto no se verán afectados sus derechos de garantía limitada.

*Le non-enregistrement du produit n'affecte aucunement vos droits en vertu de la garantie limitée.

Register your product.* Learn about the full range of services your warranty provides.

Registering online is quick and easy!
Global.Bose.com/register

To link directly to registration:

www.register.Bose.eu (Europe)

www.Bose.com/register (US, PR & USVI)

www.Bose.com.au/warranty (Australia)

www.Bose.ca/register (Canada)

www.Bose.co.nz/warranty (New Zealand)

Send any correspondence regarding product information or Limited Warranty services to our corporate headquarters at:

Product Registration

Bose Corporation

The Mountain

PO Box 9168

Framingham, MA 01701-9168 USA

1-800-736-5076 (US)

1-508-766-1000 (INTL) *Charges may apply.*

Please have your serial number available when you call.

Owners living outside the United States should check the Owner's Guide or Global.Bose.com for the nearest mailing address.

LIMITED WARRANTY

Who is covered:

This warranty is extended only to the original end-use purchaser or the person receiving the product as a gift, and shall not be extended to any other person or transferee.

What is covered/For how long:

Unless a different warranty period is stated in the Owner's Guide provided with your Bose® product, for a period of 1 year (2 years EU) [5 years for any non-powered speakers that may be incorporated into this product] from the date of retail purchase by the original end-use purchaser, Bose warrants that this product, when delivered to you in new condition, in original packaging, from a Bose authorized reseller and used in normal conditions, is free from any defects in manufacturing, materials and workmanship.

What is not covered:

This warranty does not cover defects resulting from improper or unreasonable use or maintenance; failure to follow operating instructions; accident; excess moisture; insects; lightning; power surges; connections to improper voltage supply; unauthorized alteration or modification of original condition; damages caused by inadequate packing or shipping procedures; loss of, damage to or corruption of stored data; damages caused by use with non-Bose products; product that requires modification or adaptation to enable it to operate in any country other than the country for which it was designed,

manufactured, approved and/or authorized, or repair of products damaged by these modifications; and products purchased from unauthorized dealers.

What we will do:

During the warranty period, we will, at our sole option, repair or replace (using new or refurbished replacement parts) any defective parts within a reasonable period of time and free of charge.

What we will not do:

Pay shipping, insurance or transportation charges from you to us, or any import fees, duties and taxes.

What you must do to obtain Limited Warranty Service:

Return product, with proof of purchase from an authorized Bose dealer, using the following procedures:

1. Contact the Bose organization in your country/region (visit Global.Bose.com for Bose contact information in your country/region) for specific return and shipping instructions;
2. Label and ship the product, freight prepaid, to the address provided by the Bose organization in your country; and
3. Place any necessary return authorization number prominently on the outside of the carton. Cartons not bearing a return authorization number, where required, will be refused.

Other conditions:

THE PROVISIONS OF THIS LIMITED WARRANTY ARE IN LIEU OF ANY OTHER WARRANTY, WHETHER EXPRESSED OR IMPLIED, WRITTEN OR ORAL, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. BOSE CORPORATION'S MAXIMUM LIABILITY SHALL NOT EXCEED THE ACTUAL PURCHASE PRICE PAID BY YOU FOR THE PRODUCT. IN NO EVENT SHALL BOSE BE LIABLE FOR LOSS OF, DAMAGE TO OR CORRUPTION OF STORED DATA, OR FOR SPECIAL, INCIDENTAL, CONSEQUENTIAL, OR INDIRECT DAMAGES HOWSOEVER CAUSED INCLUDING WITHOUT LIMITATION THE REPLACEMENT OF EQUIPMENT AND PROPERTY, AND ANY COSTS OF RECOVERING, PROGRAMMING OR REPRODUCING ANY PROGRAM OR DATA STORED IN OR USED WITH YOUR BOSE PRODUCT. This warranty is void if the label bearing the serial number has been removed or defaced.

Other legal rights:

This limited warranty gives you specific legal rights, and you also may have other rights that vary from state to state or country to country. Some places do not allow limitations on implied warranties or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

**Failure to register your product will not affect your limited warranty rights.*